


1. Set *Video format* to **NTSC**



Startup wizard (3/9)

Basic

System Time DST

Video format NTSC


Language English

Don't display this window again.

← Prev. → Next × Cancel

2. Set *DNS* to **Use the following DNS server addresses: 8.8.8.8 and 8.8.4.4**

**Note:** if your *Alternate DNS server* is auto-filled, do not change it to 8.8.4.4.



Subnet mask 000.000.000.000

Default gateway 000.000.000.000

Obtain DNS server address automatically

Use the following DNS server addresses


Preferred DNS server 8.8.8.8

Alternate DNS server 8.8.4.4

Don't display this window again.

← Prev. → Next × Cancel

3. Set *DDNS* to **Enable**



Startup wizard (6/9)

Application

DDNS Port

DDNS Enable

Server Disable

Enable

Don't display this window again.

← Prev. → Next × Cancel

4. Set *Port* to any unused port numbers.



**Note:** if installing multiple DVRs / NVRs in one location use incrementing port numbers.

Example:

- 1) DVR (1):
  - Media port: 6001
  - Web port: 80
- 2) DVR (2):
  - Media port: 6002
  - Web port: 81
- 3) DVR (3):
  - Media port: 6003
  - Web port: 82